

		Clean Liquids	Dirty Liquids	Corrosive Liquids	Viscous Liquids	Abrasive Slurries	Fibrous Slurries	Low Velocity Flows	Vapor Or Gas	High Temp. Service	Cryogenic Service	Semi Filled Pipes	Non Newtonian Fluids	Open Channel
DIFFERENTIAL PRESSURE	V-Cone	★	★	★	⊙	★	★	★	★	★	★			
	Orifice	★	⊙	○	○			★	★	★	★		⊙	
	Venturi	★	○	⊙	⊙	⊙	⊙	⊙	★	⊙	⊙		⊙	
	Flow Nozzles and Tubes	★	⊙	⊙	⊙	⊙	⊙	⊙	★	⊙	⊙		⊙	
	Pitot Tubes	★	⊙	○	⊙			⊙	★	⊙	⊙			
	Elbow	★	○	○	⊙	○	⊙		★	⊙	⊙		⊙	
Magnetic		★	★	★	○	★	★	○		⊙		⊙	○	⊙
MASS	Coriolis	★	★	○	★	★	○	○	⊙	⊙	⊙		★	
	Thermal	⊙	⊙	⊙	⊙	⊙	⊙	○	★	⊙			⊙	
OSCILLATORY	Vortex Shedding	★	○	○	⊙				★	⊙	⊙			
	Fluidic	★	⊙	○	⊙					⊙	⊙			
	Vortex Precession	★		⊙	⊙				★	⊙				
Positive Displacement		★		⊙	★			★	★	⊙	⊙			
Target		★	○	○	○	⊙		⊙	★	⊙	⊙		⊙	
Turbine		★	⊙	⊙	○			⊙	★	○	⊙			⊙
ULTRASONIC	Transit Time	★	⊙	⊙	⊙			⊙	⊙		⊙			⊙
	Doppler		★	⊙	⊙	⊙	⊙	⊙					⊙	
Variable Area		★	○	○	○			⊙	★	○				
Weirs and Flumes		★	○	⊙		⊙	⊙	○				★		★

Flow Meter Applications: ★ Designed for this Service, ⊙ Applicable for this Service Under Certain Conditions (Consult Manufacturer), ○ Normally Applicable for this Service, ± Not Applicable for this Service